EXCAVATING DIMENSIONS					
SYSTEM	L	W	H	I	E
FUSION 450	7'–1"	3'–8"	5'–2"	4'–4"	3'–10"
FUSION 800	8'–3"	4'–8"	6'–2"	5'–4"	4'–10"



NOTES:

1) DIMESIONS "I" AND "E" ARE TO THE BOTTOM OF THE INLET/OUTLET PIPE.
2) THE OVERALL HEIGHT DIMENSION "H" IS TO THE TOP OF THE NARROW ADAPTER RING. NOT THE RISER LID.
3) A RISER COVER COMES STANDARD. ADDITIONAL RISERS ARE PURCHASED SEPARATELY.

FUSION 450 – DIMENSIONS & EXCAVATION DETAILS

NTS



FOR ILLUSTRATION PURPOSES ONLY
REFER TO SCHEMATIC LOCATED IN PANEL FOR INSTALLATION

BLOWER FOR ZF–450 AND ZF–800

PANEL SCHEMATIC

NTS



FUSION 450 – AIR COMPRESSOR DETAILS

NTS



FUSION 450 – TYPICAL PROFILE

NTS



AIR COMPRESSOR INSTALLATION

NTS

ONSITE EQUIPMENT, INC
(315) 254-6891
www.onsite-engineering.us - Eric@onsite-engineering.us

PROJECT LOCATION

CLARUS FUSION 450
ENHANCED TREATMENT UNIT
CUT SHEET – INSTALLATION OVERVIEW

OWNER ADDRESS

CLARUS ENHANCED TREATMENT UNIT DETAILS

FILE NUMBER
EEM2017

DATE
02–20–2021

FIGURE NO.
CF450